

## Table of Contents

<b>1. Introduction.....</b>	<b>6</b>
1.1. Computer Minimum System Requirements .....	7
1.2. Supported Formats.....	8
1.3. Box Content .....	9
1.4. Languages .....	9
1.5. Supported Subtitles .....	10
1.6. Views of the LaCinema PlayHD .....	10
1.6.1. Front View .....	10
1.6.2. Rear View .....	10
1.7. Cables and Connectors.....	11
1.7.1. A/V (Audio/Video) Cables .....	11
1.7.2. USB Cable.....	11
<b>2. Using the Remote Control .....</b>	<b>12</b>
2.1. Battery Installation.....	12
2.2. Remote Control Key Index .....	13
2.2.1. Important Button Details.....	14
<b>3. Setting Up: Transferring Files .....</b>	<b>15</b>
3.1. STEP 1: Connect the Power Supply .....	16
3.2. STEP 2: Connect the USB cable .....	17
3.2.1. Media File Organization on the LaCinema PlayHD.....	17
3.3. STEP 3: Unmounting Your Drive.....	18
<b>4. Setting Up: TV Connection .....</b>	<b>19</b>
4.1. STEP 1: Connect HDMI or Composite Video/Stereo Audio Cables .....	19
4.1.1. HDMI (High Definition) Connection.....	20
4.1.2. Composite Video & Stereo Audio Cable .....	20
4.1.3. Coaxial Audio Connection .....	21
4.2. STEP 3: Connect the Power Supply .....	22
4.2.1. USB and TV Simultaneous Connection Warning .....	22
4.3. STEP 4: Complete the Installation Wizard.....	23
<b>5. Playing Multimedia Files.....</b>	<b>24</b>
5.1. Movie Space .....	24
5.1.1. Movie Space Options .....	25
5.2. Photos Space.....	27
5.2.1. Music During Your Slide Shows.....	27
5.2.2. Photo Space Options.....	27
5.3. Music Space.....	30
5.3.1. Music Space Options.....	30
<b>6. Playing Files Located on a USB Hard Drive.....</b>	<b>31</b>
6.1. USB Disk Connection .....	31
6.2. Compatibility.....	32
6.3. Safe USB Disk Removal .....	32
<b>7. Settings Menu .....</b>	<b>33</b>
7.1. Settings: General .....	33
7.1.1. Menu Language .....	33
7.1.2. Subtitle Format.....	34
7.1.3. Screen Saver.....	34

---

7.1.4. Media Library .....	34
7.2. Settings: Audio/Video .....	35
7.2.1. Resolution .....	35
7.2.2. Aspect Ratio .....	35
7.2.3. HDMI Audio .....	36
7.2.4. S/PDIF Audio .....	36
7.2.5. 1080P 24Hz .....	36
7.3. Settings: System .....	37
7.3.1. Version .....	37
7.3.2. Firmware Update .....	37
7.3.3. HDD Format (Formatting the internal hard disk) .....	38
7.3.4. Factory Default .....	38
<b>8. Reformatting the LaCinema PlayHD Hard Disk .....</b>	<b>39</b>
8.1. Reformatting: Windows .....	40
8.1.1. Formatting for Windows XP .....	40
8.1.2. Formatting for Windows Vista/7 .....	43
8.2. Reformatting: Mac Users .....	47
8.3. Reformatting: The LaCinema PlayHD TV Menu .....	49
<b>9. Technical Information .....</b>	<b>51</b>
9.1. HD File Format Compatibility .....	51
9.2. Optimizing Data Transfers .....	51
<b>10. Troubleshooting .....</b>	<b>52</b>
10.1. Troubleshooting the Television/Stereo Connection .....	53
10.2. USB Connection (Mac Users) .....	54
10.3. USB Connection (Windows Users) .....	55
<b>11. Contacting Customer Support .....</b>	<b>56</b>
11.1. LaCie Technical Support Contacts .....	57
<b>12. Warranty Information .....</b>	<b>58</b>

## Copyrights

Copyright © 2010 LaCie. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of LaCie.

## Trademarks

Apple, Mac, and Macintosh are registered trademarks of Apple Inc. Microsoft, Windows XP, Windows Vista, and Windows 7 are registered trademarks of Microsoft Corporation. Other trademarks mentioned in this manual are the property of their respective owners.

Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.



Manufactured under license under U.S. Patent #: 5,451,942 & other U.S. and worldwide patents issued & pending. DTS and the Symbol are registered trademarks and DTS Digital Out and the DTS logos are trademarks of DTS, Inc. Product includes software. © DTS, Inc. All Rights Reserved.



## Changes

The material in this document is for information only and subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, LaCie assumes no liability resulting from errors or omissions

in this document, or from the use of the information contained herein. LaCie reserves the right to make changes or revisions in the product design or the product manual without reservation and without obligation to notify any person of such revisions and changes.

## Canada Compliance Statement

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

## Manufacturer's Declaration for CE Certification

We, LaCie, solemnly declare that this product conforms to the following European standards: Class B EN60950, EN55022, EN55024, EN61000-3-2: 2000, EN61000-3-3: 2001

With reference to the following conditions: 73/23/EEC Low Voltage Directive; 89/336/EEC EMC Directive

---

**CAUTION:** Modifications not authorized by the manufacturer may void the user's authority to operate this device.

---

---

**CAUTION:** The LaCinema PlayHD's warranty may be void as a result of the failure to respect the precautions listed above.

---

---

**NOTE:** The main cable must be in conformity with CEI 60227 or CEI 60245 and the type of plug must match the standards in the country of use.

---



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designed collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service, or the shop where you purchased the product.

---

**CAUTION:** The LaCinema PlayHD's warranty may be void as a result of the failure to respect the precautions listed above.

---

## Health and Safety Precautions

- ◆ Only qualified persons are authorized to carry out maintenance on this device.
- ◆ Read this User Manual carefully and follow the correct procedure when setting up the device.
- ◆ Do not open a disk drive or attempt to disassemble or modify it. Never insert any metallic object into the drive to avoid any risk of electrical shock, fire, short-circuiting or dangerous emissions. The disk drives shipped with your LaCinema PlayHD contain no user-serviceable parts. If it appears to be malfunctioning, have it inspected by a qualified LaCie Technical Support representative.
- ◆ Never expose your device to rain, or use it near water, or in damp or wet conditions. Never place objects containing liquids on the LaCinema PlayHD, as they may spill into its openings. Doing so increases the risk of electrical shock, short-circuiting, fire or personal injury.
- ◆ Make sure that the computer and LaCinema PlayHD are electrically grounded. If the devices are not grounded, there is an increased risk of electrical shock. Power requirements 100-240 V~, 1.5 A, 60-50 Hz, (Supply voltage fluctuations not exceeding  $\pm 10\%$  of the nominal, transient over-voltages according to over-voltage category II).

---

## General Use Precautions

- ◆ Do not expose the LaCinema PlayHD to temperatures outside the range of 5° C to 30° C (41° F to 86° F); or to operational humidity beyond 5-80%, non-condensing, or non-operating humidity beyond 10-90%, non-condensing. Doing so may damage the LaCinema PlayHD or disfigure its casing. Avoid placing your LaCinema PlayHD near a source of heat or exposing it to sunlight (even through a window). Inversely, placing your LaCinema PlayHD in an environment that is too cold or humid may damage the unit.
- ◆ Always unplug the LaCinema PlayHD from the electrical outlet if there is a risk of lightning or if it will be unused for an extended period of time. Otherwise, there is an increased risk of electrical shock, short-circuiting or fire.
- ◆ Use only the power supply shipped with the device.
- ◆ Do not place objects on top of the LaCinema PlayHD or use excessive force on it.
- ◆ Never use excessive force on your LaCinema PlayHD. If you detect a problem, see the Troubleshooting section in this manual.

---

**CAUTION:** A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.

---

## Operating Environment Temperatures

- ◆ Do not expose the LaCinema PlayHD to temperatures outside the range of 5° C to 30° C (41° F to 86° F). As high end audio/video appliance, the LaCinema PlayHD has been designed with an efficient ventilation system. Allow 5 cm of clearance for airflow on all sides of the LaCinema PlayHD to prevent overheating. See [Fig. 01](#).
- ◆ Do not stack the LaCinema PlayHD on another audio/video appliance such as a TV, VCR or DVD player. Other audio/video appliances require sufficient airflow and carry the same precautions of use. See [Fig. 02](#) and [Fig. 03](#).

---

**IMPORTANT INFO:** Any loss, corruption or destruction of data while using a LaCie drive is the sole responsibility of the user, and under no circumstances will LaCie be held liable for the recovery or restoration of this data. To help prevent the loss of your data, LaCie highly recommends that you keep **TWO** copies of your data; one copy on your external hard disk, for instance, and a second copy either on your internal hard disk, another external hard disk or some other form of removable storage media. LaCie offers a complete line of CD and DVD drives. If you would like more information on backup, please refer to our website.

---

---

**IMPORTANT INFO:** 1GB = 1,000,000,000 bytes. 1TB = 1,000,000,000,000 bytes. Once formatted, the actual available storage capacity varies depending on operating environment (typically 5-10% less).

---




Fig. 01




Fig. 02




Fig. 03

# 1. Introduction

Congratulations on the purchase of your new LaCinema PlayHD! Simply connect the LaCinema PlayHD to your TV and use the included remote for easy navigation. The intuitive PlayHD menus are called [Spaces](#) and they give you easy access to watch high definition movies, view photos or listen to music.

The LaCinema PlayHD allows you to choose from MPG, AVI, MP4, MKV, WMV, MOV, RMVB, ISO, VOB, IFO, ASF, TS, TP, TRP, MTS, M2TS, and DAT video formats for easy playback.

## Quick Links

### Click a topic:

- ◆ [Setting Up: Transferring Files](#)
- ◆ [Setting Up: TV Connection](#)
- ◆ [Playing Multimedia Files](#)



## 1.1. Computer Minimum System Requirements

- ◆ Latest version of:
    - Windows XP®, Windows Vista®, or Windows 7®
    - or
    - Mac® OS X 10.5 or 10.6
  - ◆ USB interface port
  - ◆ Internet connection (for downloading LaCinema PlayHD firmware updates)
-

## 1.2. Supported Formats

Video Codecs		
◆ MPEG-1	◆ Xvid	◆ Real Video
◆ MPEG-2 / HD	◆ H.264 HD	
◆ MPEG4	◆ WMV9 HD	
◆ DivX / HD	◆ VC-1	
	◆ AVC HD	
Video File Types (Containers)		
◆ AVI	◆ MOV	◆ FLV
◆ MP4	◆ MPEG	◆ M2TS
◆ MKV	◆ VOB	◆ DVR-MS
◆ WMV	◆ ASF	◆ ISO*
◆ MPG	◆ TS	◆ Video_TS*
◆ DAT	◆ RMVB	◆ M4V
◆ M2V	◆ M1V	◆ AVC
External Hard Drive File Systems		
◆ HFS+ (non-Journaled)	◆ FAT32	◆ Ext2
	◆ NTFS	◆ Ext3
Subtitles		
◆ SUB (Vobsub, Subviewer)	◆ SSA	◆ SRT
◆ SMI		
Audio File Types (Containers)		
◆ MP3	◆ AAC**	◆ AC3
◆ WMA	◆ OGG	◆ MP4
◆ WAV/LPCM	◆ FLAC	◆ MKA
◆ ALAC	◆ ASF	◆ APE
◆ MP1	◆ MP2	◆ MPA
Playlists		
◆ M3U		

Photo File Types		
◆ PNG	◆ BMP	◆ TIFF
◆ GIF	◆ JPEG (except Progressive JPEG)	
Video Outputs		
◆ Composite (CVBS)		◆ HDMI 1.3
Audio Outputs		
◆ Coaxial		◆ Stereo
Dolby Digital® & DTS®		
◆ Two channels only***		
◆ Multichannel decoding via optical S/PDIF and HDMI to home amplifier		

\* DVD Video function is supported via VOB / IFO (Video\_TS folder). If the drive is formatted in FAT32, DVD ISO file size cannot exceed 4GB due to file system format limitation.

\*\* Supports iTunes encoded (m4a).

\*\*\* For audio with more than two channels, connect the product to a digital home receiver. The audio is passed through the HDMI and coaxial connections (see 4.1.1. [HDMI \(High Definition\) Connection](#), 4.1.3. [Coaxial Audio Connection](#), 7.2.3. [HDMI Audio](#) and 7.2.4. [S/PDIF Audio](#)).

**TECHNICAL NOTE:** A container, such as AVI or MOV, is a file format that defines how the data stream is stored. They contain data that has been compressed using a codec. For a file to play properly on your LaCinema PlayHD, both its codec and container type must be supported.

**TECHNICAL NOTE:** To identify the codec and container for a media file, download LaCie Media Info at <http://www.lacie.com/us/support/drivers/driver.htm?id=10202>.

## 1.3. Box Content

Your LaCinema PlayHD package contains the items listed below:

1. LaCinema PlayHD
2. Remote control
3. 2 x AAA batteries
4. HDMI cable
5. USB cable
6. External power supply
7. Quick Install Guide
8. LaCie Utilities CD-ROM (with the User Manual and Media Info software)

---

**IMPORTANT INFO:** Please save your packaging. In the event that the drive should need to be repaired or serviced, it must be returned in its original packaging.

---


## 1.4. Languages

### Supported Languages

- |           |                       |
|-----------|-----------------------|
| ◆ English | ◆ Polish              |
| ◆ French  | ◆ Swedish             |
| ◆ Italian | ◆ Simplified Chinese  |
| ◆ German  | ◆ Traditional Chinese |
| ◆ Spanish | ◆ Japanese            |
| ◆ Greek   | ◆ Korean              |
| ◆ Russian |                       |

Please check the LaCie website for a complete list of supported languages.

---



## 1.5. Supported Subtitles

The LaCinema PlayHD supports the following subtitle formats, listed by font code:

- ◆ Western Europe (ISO)
- ◆ Central Europe (ISO, Windows-1250 )
- ◆ Greek (ISO, Windows-1253)
- ◆ Cyrillic (Windows-1251)
- ◆ Cyrillic (KOI8-R)
- ◆ Traditional Chinese (Big5)
- ◆ Simplified Chinese (GB18030)
- ◆ Japanese (Shift-JIS)
- ◆ Korean (EUC-KR)
- ◆ Arabic (Windows-1256)

## 1.6. Views of the LaCinema PlayHD

### 1.6.1. Front View

1. Infrared receiver – Receives the infrared signal from the remote control. Make sure the receiver is not obstructed.
2. Disk status LED – A flickering light indicates disk activity.
3. USB expansion port (host) – Connect a USB flash disk, key, hard disk, or card reader to access its multimedia files directly from your TV. You may also connect a camera with photos or video.

### 1.6.2. Rear View

1. Power connector – Connect the power supply
2. USB 2.0 (device) – Connect to the USB 2.0 port of your computer to transfer media files
3. HDMI – Connect to a compatible TV or video projector
4. Audio (white and red) – Connect to the audio input of a TV or receiver/pre-amplifier
5. Video out (yellow) – Connect to a compatible TV
6. Coaxial audio out – Connect to a compatible digital receiver/pre-amplifier




Fig. 04




Fig. 05

## 1.7. Cables and Connectors

### 1.7.1. A/V (Audio/Video) Cables

Audio/video cables supported by the LaCinema PlayHD:

1. HDMI (High-Definition Multimedia Interface - included with the box contents) – The optimal audio/video connection from the LaCinema PlayHD to compatible televisions.
2. Composite video/Stereo audio (not included) – Standard analog video and audio connections. The yellow RCA plug is for video while the white (left channel) and red (right channel) are for audio. If your TV only has a SCART connection, you can purchase a SCART-Composite adapter from your local retailer.
3. Coaxial Audio (S/PDIF) (not pictured/not included) – Connect your LaCinema PlayHD to a digital receiver/pre-amplifier for surround sound formats.

### 1.7.2. USB Cable

USB is a serial input/output technology for connecting peripheral devices to a computer or to each other. Hi-Speed USB 2.0 is the provides the necessary bandwidth and data transfer rates to support high speed devices such as hard drives, CD/DVD drives, and digital cameras.

**NOTE:** Your LaCinema PlayHD is shipped with a Hi-Speed USB 2.0 cable to connect the device to a PC or Mac. It plugs into the rear USB 2.0 device port of the PlayHD. You may connect a USB peripheral to the LaCinema PlayHD’s front USB 2.0 port. USB peripherals include digital cameras, USB drives, USB flash drives and keys, etc. Please use the USB cable that shipped with the peripheral.

**TECHNICAL NOTE:** The included device cable will also work when connected to a USB port, but drive performance will be limited to USB 1.1 transfer rates. To achieve Hi-Speed USB 2.0 data transfer rates, you must be connected to a Hi-Speed USB 2.0 host interface.




Fig. 06

	Connection	Maximum Resolution
High Definition	HDMI (Digital)	1080p
Standard Definition	Composite (Analog)	576i




Fig. 07 - USB cable ends

## 2. Using the Remote Control

### 2.1. Battery Installation

Please install the included AAA batteries before using the remote control.

#### To install the batteries:

1. Remove the battery compartment cover.
2. Load the batteries onto the battery compartment. Position the batteries so that the “+” symbols on the batteries face the same direction as the “+” symbols on the battery compartment.
3. Slide the battery compartment cover back into the remote.

---

**IMPORTANT INFO:** If you will not use the remote control for an extended period of time, LaCie recommends removing the batteries. Replace the batteries when you use the remote control.

---

---

**IMPORTANT INFO:** The remote control must be pointed at the infrared receiver on the LaCinema PlayHD. The receiver must be no further than 23 feet (7 meters) from the remote control. [Fig. 08](#)

---




Fig. 08

## 2.2. Remote Control Key Index

The included remote control allows you to set up and use the LaCinema PlayHD while it is connected to your TV.

Button
<b>1.</b> Power
<b>2.</b> Previous
<b>3.</b> Stop
<b>4.</b> Play/Pause
<b>5.</b> Back (previous screen)
<b>6.</b> Up
<b>7.</b> Left/Rewind
<b>8.</b> Info
<b>9.</b> Volume
<b>10.</b> Eject
<b>11.</b> Home
<b>12.</b> Next
<b>13.</b> Mute
<b>14.</b> Favorite
<b>15.</b> OK
<b>16.</b> Right/Fast Forward
<b>17.</b> Down
<b>18.</b> Settings
<b>19.</b> Search/Go To
<b>20.</b> Page




Fig. 09

### 2.2.1. Important Button Details

1. **Return:** Go back to the previous menu.
2. **OK:** Confirm a selection.
3. **Settings button:** Display the available settings or actions in the different media spaces. During playback, this button will bring up a contextual menu to adjust the settings.




Fig. 10

## 3. Setting Up: Transferring Files

This chapter explains how to transfer files to the LaCinema PlayHD from your computer via USB. Learn how to play files stored on a USB disk drive or flash drive in section [6. Playing Files Located on a USB Hard Drive](#).

The USB connection consists of the following steps:

3.1. STEP 1: *Connect the Power Supply*

3.2. STEP 2: *Connect the USB cable*

3.3. STEP 3: *Unmounting Your Drive*

When you have finished transferring files, safely disconnect the USB cable and proceed to chapter [4. Setting Up: TV Connection](#).




Fig. 11

### 3.1. STEP 1: Connect the Power Supply

1. Plug one end of the power adapter cord into the back of the LaCinema PlayHD and the other end into an active power outlet (Fig. 12).
2. Move to the next step, [3.2. STEP 2: Connect the USB cable](#).

---

**CAUTION:** Only use the AC adapter supplied with your specific LaCie device. Since each product is unique, do not substitute a power supply from another LaCie device or another manufacturer for the LaCinema PlayHD.

Please note that the AC adapter provided with your LaCie device includes connectors for electrical outlets in multiple regions. Thanks to its 100-240 Volt power supply, you may use your device in a foreign country. However, LaCie accepts no responsibility for any damage to the drive resulting from the use of an inappropriate adapter.

Further, your warranty will be void if you:

- ◆ Use any other power cable, power supply, or power adapter other than one that has been authorized by LaCie.
  - ◆ Do not remove your AC adapter when transporting your LaCie device. Doing so may damage your LaCinema PlayHD.
- 




Fig. 12

## 3.2. STEP 2: Connect the USB cable

1. Make sure the power cable is connected as described in section 3.1. *STEP 1: Connect the Power Supply*.
2. Connect one end of the USB cable to your computer (Fig. 13) and the other end to the USB port on the rear of the LaCinema PlayHD (Fig. 14).

### Windows Users

- a. The drive will mount in My Computer/Computer (Fig. 15).
- b. Copy multimedia files to the mounted volume.

### Mac Users

- a. The drive is preformatted and optimized for NTFS. For information on how to use the drive with your Mac, go to section 8.2. *Reformatting: Mac Users*. Once the PlayHD is compatible with your Mac, proceed to step b below.
  - b. The drive will mount on your Desktop.
  - c. Copy multimedia files to the mounted volume.
3. Unmount the drive and unplug the USB cable before connecting the drive to your television (see 3.3. *STEP 3: Unmounting Your Drive*).

### 3.2.1. Media File Organization on the LaCinema PlayHD

You can copy files directly onto the root level of the LaCinema PlayHD hard disk. For easy organization, the LaCinema PlayHD operating system places the file types in their own *Spaces* (i.e. *Movie Space*, *Music Space*, and *Photo Space*; see 5. *Playing Multimedia Files*). Of course, you may also create folders on the PlayHD hard disk for browsing content according to your own preference. When operating the PlayHD, you have the option to view files by *Folder* from within each media space.

---

**IMPORTANT INFO:** To avoid data corruption, make sure to unmount your drive before disconnecting the USB cable. See 3.3. *STEP 3: Unmounting Your Drive* for details.

---



---

**IMPORTANT INFO:** The drive cannot be connected to your computer via USB and to the television simultaneously.

---




Fig. 13




Fig. 14




Fig. 15

### 3.3. STEP 3: Unmounting Your Drive

The LaCinema PlayHD behaves like an external USB device when it is connected to your computer via USB. LaCie highly recommends that you unmount the PlayHD disk drive volume before unplugging the USB cable.

#### Windows XP

From the system tray (located in the lower right-hand side of your screen), click the **Eject** icon (a small green arrow over a hardware image) (Fig. 16 - Windows XP).

A message will appear, listing the devices the Eject icon controls (it should say, "Safely remove..."). Click on the LaCinema PlayHD in this prompt.

You will receive a message that it is safe to remove hardware. It is now safe to disconnect the device.




Fig. 16 - Windows XP



Fig. 17 - Windows Vista/7

#### Windows Vista/7

From the system tray located in the lower right-hand side of your screen, right-click on the plug icon (note the white check mark inside a green circle). Fig. 17 - Windows Vista/7

Select the small message **Safely Remove Hardware**. From the window prompt, choose the LaCinema PlayHD and select **Stop**. A second window may open to confirm your selection. Select the LaCinema PlayHD and click **OK**.

A message will appear noting that it is safe to remove the device.




Fig. 18 - Mac

#### Mac

Drag the LaCinema PlayHD drive icon to the trash (Fig. 18 - Mac). The icon in the illustration is a generic USB device icon. Your drive may be represented by an icon that looks like the drive itself.

When the icon disappears from the desktop, the drive can be disconnected.

## 4. Setting Up: TV Connection

This chapter explains how to connect your LaCinema PlayHD to your television in order to browse and play files. Once the connection is established, go to section 5. *Playing Multimedia Files* for information on playing files. Setup consists of these steps:

- 4.1. STEP 1: Connect HDMI or Composite Video/Stereo Audio Cables
- 4.2. STEP 3: Connect the Power Supply
- 4.3. STEP 4: Complete the Installation Wizard

### 4.1. STEP 1: Connect HDMI or Composite Video/Stereo Audio Cables

**IMPORTANT INFO:** The LaCinema PlayHD cannot be connected to a TV and a computer at the same time. Disconnect the USB cable before proceeding (see 3.3. *STEP 3: Unmounting Your Drive*).

The LaCinema PlayHD may be connected to your television via:

- ◆ HDMI (section 4.1.1. *HDMI (High Definition) Connection*)
- ◆ Composite (section 4.1.2. *Composite Video & Stereo Audio Cable*)

You may also connect the LaCinema PlayHD coaxial output to a receiver/pre-amplifier to take advantage of surround sound formats. (see 4.1.3. *Coaxial Audio Connection* for details).

**TECHNICAL NOTE:** Please note that the HDMI cable also carries digital surround sound formats along with the picture signal. See the user manual for your digital receiver/pre-amplifier to determine the optimal connection. This User Manual will assume a connection directly to your television.




Fig. 19

	Connection	Maximum Resolution
High Definition	HDMI (Digital)	1080p
Standard Definition	Composite (Analog)	576i

Picture quality for HDMI and composite video.

#### 4.1.1. HDMI (High Definition) Connection

1. Connect one end of the HDMI cable to your television's HDMI port (Fig. 20).
2. Connect the other end of the HDMI cable to the corresponding port on the LaCinema PlayHD (Fig. 20).
3. Go to the next step, [4.2. STEP 3: Connect the Power Supply](#).

#### 4.1.2. Composite Video & Stereo Audio Cable

1. Connect the three RCA-type ends of composite video and stereo audio cables (not included) to the proper ports on your television (Fig. 21).
2. Connect the other ends of the composite video and stereo audio cables (not included) to the corresponding ports on the LaCinema PlayHD (Fig. 21).
3. Move to the next step, [4.2. STEP 3: Connect the Power Supply](#).

**IMPORTANT INFO:** Before connecting the cables, make sure your TV is turned off.

**TECHNICAL NOTE:** The connectors on the rear of your TV may not appear exactly the same as the illustrations in this User Manual. Please read the labels next to the connectors to ensure correct connections.




Fig. 20 - HDMI connection




Fig. 21 - Composite connection

4.1.3. Coaxial Audio Connection

You may use the coaxial audio connection (cable not included) to pass surround sound formats to a digital receiver/pre-amplifier. Please note that you will require an RCA type connector for the coaxial connection (not included).

**IMPORTANT INFO:** Before connecting the cable, power off your digital receiver/pre-amplifier.

- 1. Connect one end of a coaxial audio cable to your digital receiver/pre-amplifier (*Fig. 22 - Coaxial connection*).
- 2. Connect the other end of the cable to the back of the LaCinema PlayHD (*Fig. 22 - Coaxial connection*).
- 3. Move on to the next step, *4.2. STEP 3: Connect the Power Supply*.

4.1.3.1. Enabling Surround Sound Pass-through - Coaxial Connection

After completing the LaCinema PlayHD on-screen setup, you can enable coaxial *Pass through* for surround signals:

- 1. Using the PlayHD remote control, go to **Home Menu > Setup > Audio/Video > S/PDIF Audio** (*Fig. 23* and *Fig. 24*).
- 2. Select **Pass through** (*Fig. 25*).




Fig. 22 - Coaxial connection




Fig. 23



Fig. 24



Fig. 25

## 4.2. STEP 3: Connect the Power Supply

**IMPORTANT INFO:** If your power supply cable is already connected, turn on your TV and skip to [4.3. STEP 4: Complete the Installation Wizard](#).

1. Plug one end of the power adapter cord into the back of LaCinema PlayHD and the other end into a power outlet ([Fig. 26](#)).
2. Turn on your television.

**TECHNICAL NOTE:** If you do not see the PlayHD loading screen, you may have to adjust the video input on your TV. Consult the user manual for your television to determine how to select the video input signal. The video signal must match the video cable used to connect the LaCinema PlayHD to the television: HDMI or composite ([Fig. 27](#)).

3. Move on to the next step, [4.3. STEP 4: Complete the Installation Wizard](#).

### 4.2.1. USB and TV Simultaneous Connection Warning

Your LaCinema PlayHD should be attached to a computer to receive media files ([3.2. STEP 2: Connect the USB cable](#)). Once the files have been copied to the PlayHD disk drive, please disconnect it safely from your computer in order to watch and listen to your content on a television ([3.3. STEP 3: Unmounting Your Drive](#) and [4.1. STEP 1: Connect HDMI or Composite Video/Stereo Audio Cables](#)).

Please do not connect the LaCinema PlayHD to a computer and a television at the same time. The device will warn you to disconnect one of the cables if it senses computer and audio/video signals at the same time ([Fig. 28](#)).




Fig. 26




Fig. 27



Fig. 28

### 4.3. STEP 4: Complete the Installation Wizard

The first time you turn on the LaCinema PlayHD, an installation wizard appears to help you configure the basic settings. The wizard will only appear the first time you turn on the LaCinema PlayHD or after a reset to factory default (7.3.4. *Factory Default*).

1. Make certain that:
  - ◆ The LaCinema PlayHD is connected to the TV
  - ◆ The power supply has been connected
  - ◆ The TV is turned on
2. A startup screen will appear during product initialization.
3. Select your language using the **Up** ▲ and **Down** ▼ buttons (Fig. 29). Confirm the selection by pushing the **OK** button.
4. You will see a diagram of your PlayHD remote control. It is similar to 2.2. *Remote Control Key Index*. Click **Next** (Fig. 30).
5. Setup is finished. For further details, go to 5. *Playing Multimedia Files*. (Fig. 31).



Fig. 29




Fig. 30




Fig. 31

## 5. Playing Multimedia Files

This chapter explains how to use the LaCinema PlayHD interface and play files from its hard disk. For information on playing files from external sources, refer to section [6. Playing Files Located on a USB Hard Drive](#).

To access your files, use the remote control to browse through the different media spaces – [Movie](#), [Photo](#), or [Music](#).

The following section outlines how to play files for each media space.

Related Section

◆ [6. Playing Files Located on a USB Hard Drive](#)

File Type	Section
Movies	<a href="#">5.1.1. Movie Space Options</a>
Photos	<a href="#">5.2. Photos Space</a>
Music	<a href="#">5.3. Music Space</a>

### 5.1. Movie Space

Navigate to the Movies Space using the [Left](#) ◀ and [Right](#) ▶ buttons. Then use the [Up](#) ▲ and [Down](#) ▼ buttons to select the Movie Space ([Fig. 32](#)).

The Movie Space will display all supported video files that are accessible to the LaCinema PlayHD ([1.2. Supported Formats](#)). Music and Photo files will not be displayed.

Files are organized according to their location. For example, whether they are stored on the LaCinema PlayHD internal storage or an external USB hard drive.

To load a movie, select the file you wish to play and press the **OK** button. A loading animation will appear while the it is being analyzed to ensure optimum playback experience.

**NOTE:** If you stop a film and then return to it later, the LaCinema PlayHD will ask if you want to play from where you left off. You may also start from the beginning.







Fig. 32

5.1.1. Movie Space Options

While a movie is playing, you can adjust several playback parameters. Press the **Setup**  button to display or exit the on-screen menu. Use the **Left**  and **Right**  buttons to navigate to a setting and click **OK** to enter the setting menu. To confirm a setting, click the **OK** button.

Movie Space Menu (*Fig. 33*):

- 1. Audio
- 2. Subtitles
- 3. Play Mode
- 4. Video Settings
- 5. Go To
- 6. Zoom In/Zoom Out

Audio Languages (*Fig. 34*)

Modify the audio language if alternates are available.

Subtitle (*Fig. 35*)

- ◆ Activate or modify the encoding language
- ◆ Change the position, color, and size of subtitles
- ◆ Synchronize subtitles that are not properly timed to the audio

[continued on the next page >>](#)




Fig. 33




Fig. 34




Fig. 35

### Play Mode

Choose how to play back a movie:

- ◆ Normal playback
- ◆ Repeat one will play back the same file until it is stopped.
- ◆ Repeat all will play all the movie files in the same folder. The movie files are played back according to their order in the folder.

### Video Settings (Fig. 36)

Modify the display:

- ◆ Brightness
- ◆ Contrast
- ◆ Saturation
- ◆ Hue




Fig. 36

### Go To (Fig. 37)

Select the playback position by:

- ◆ Hour: Minutes: Seconds
- ◆ Chapter

### Zoom In/Zoom Out

- ◆ Select this option than the **Up** ▲ button to zoom into the image.
- ◆ Select this option than the **Down** ▼ button to zoom away from the image.

**Display info:** Click the **i** button to display information about the current file. Information includes time remaining, time elapsed, etc.

**Exit Setup:** To exit the on-screen menu, click the **Setup** ⚙ button.




Fig. 37

## 5.2. Photos Space

Navigate to the Photo Space using the **Left** ◀ and **Right** ▶ buttons (Fig. 38). Then use the **Up** ▲ and **Down** ▼ buttons to browse within the Photo Space.

The Photo Space will display all supported photo files that are accessible to the LaCinema PlayHD (1.2. Supported Formats). Music and video files will not be displayed.

Files are organized according to their location. For example, whether they are stored on the LaCinema PlayHD internal storage or an external USB hard drive.

To load a picture, select the image you wish to display and press the **OK** button.




Fig. 38

### 5.2.1. Music During Your Slide Shows

There are two ways to play music while watching a photo slideshow (Fig. 39):

1. Choose the **Select Music** option in the Photo Space
2. Manually navigate between the Music and Photo Spaces.
  - ◆ Start the music track in the **Music Space**.
  - ◆ While the music track is playing, press the **Home** button to navigate to the **Photo Space** to start your slideshow.
  - ◆ Select the track you wish to play and press the **OK** button.




Fig. 39

### 5.2.2. Photo Space Options

You can adjust several playback parameters while a photo is being displayed. Press the **Setup** ⚙ button to display or exit the on-screen menu. Use the **Left** ◀ and **Right** ▶ buttons to navigate to a setting and **OK** to adjust. Once you've selected the option you want, click the **OK** button.

Photo Space Menu (Fig. 40):

1. Timing
2. Transition
3. Repeat
4. Select Music
5. Photo Settings




Fig. 40

continued on the next page >>

### Timing

Select the transition time between photos during a slideshow (Fig. 41).

### Transition

Choose the transition effect between photos during a slideshow (Fig. 42).

### Repeat

Select the playback mode (Fig. 43):

- ◆ Normal
- ◆ Shuffle
- ◆ Repeat one - the current photo will repeat continuously
- ◆ Repeat all - all files in the current folder will play in succession until stopped

[continued on the next page >>](#)




Fig. 41



Fig. 42



Fig. 43

### Select Music (Fig. 44)

Play music while watching a slideshow. You will have the option to go directly to the Music Space to select the track that fits best with your slideshow.

### Photo Settings (Fig. 45)

Modify the display:

- ◆ Brightness
- ◆ Contrast
- ◆ Saturation
- ◆ Hue

**Rotate a photo right:** Rotate the photo 90° clockwise by pushing the **Up ▲** button.

**Rotate a photo left:** Rotate the photo 90° counter-clockwise by pushing the **Down ▼** button.

**Display info:** Click the **i** button to display information about the current file.

**Exit Setup:** To exit the on-screen menu, click the **Setup ⚙** button.




Fig. 44



Fig. 45

## 5.3. Music Space

Navigate to the Music Space using the **Left** ◀ and **Right** ▶ buttons (Fig. 46). Use the **Up** ▲ and **Down** ▼ buttons to browse within the Music Space.

The Music Space will display all of the supported music files that are accessible to the LaCinema PlayHD. Only files recognized as audio files will be displayed (1.2. *Supported Formats*). Photo and video files will not be displayed.

Files are organized according to their location. For example, whether they are stored on the LaCinema PlayHD internal storage or an external USB hard drive.

To load a track, select the music file you wish to hear and press the **OK** button.

### Music During Your Slide Shows

There are two ways to play music while watching a photo slideshow:

1. Choose the **Select Music** option in the Photo Space
2. Manually navigate between the **Music** and **Photo Spaces**.
  - ◆ Start the music track in the **Music Space**.
  - ◆ While the music track is playing, press the **Home** button to navigate to the **Photo Space** to start your slideshow.
  - ◆ Select the track you wish to play and press the **OK** button.

#### 5.3.1. Music Space Options

During playback, you can adjust several parameters (Fig. 47). Press the **Setup** ⚙ button to display or exit the on-screen menu. You can navigate the music settings to adjust playback. Click the **OK** button to confirm your selection.

1. **Normal**: The currently playing file will repeat continuously.
2. **Repeat one**: The currently track will repeat until it is stopped.
3. **Repeat all**: All files in the current folder will play in succession until it is stopped.
4. **Shuffle**: Files in the current folder or playlist will play in random order.
5. **Shuffle repeat all**: Files in the current folder or playlist will play in random order.




Fig. 46




Fig. 47

## 6. Playing Files Located on a USB Hard Drive

The LaCinema PlayHD can play multimedia files stored on external USB drives. Simply plug an external USB hard disk or flash drive into the front USB 2.0 port (Fig. 49 and Fig. 50) and navigate to the files using the LaCinema PlayHD menu.

### 6.1. USB Disk Connection

1. Connect the external USB hard drive to your computer to transfer multimedia files. Unmount the drive safely from your computer (Fig. 48).
2. If it is not set up, connect your LaCinema PlayHD to your television (4. *Setting Up: TV Connection* - Fig. 49).
3. Power on the external hard disk (if applicable) and plug its USB cable into the LaCinema PlayHD's front USB device slot (Fig. 49 and Fig. 50).

[continued on the next page >>](#)




Fig. 48




Fig. 49




Fig. 50

4. Use the remote control to navigate to one of the Media Spaces ([Movies](#), [Photos](#), or [Music](#)). Files located on the external USB hard drive can be accessed under [USB1](#) ([Fig. 51](#)).

## 6.2. Compatibility


In addition to hard disks, you can connect card readers, digital cameras, or digital camcorders with USB Mass storage support.

Hard drives with the following file system formats are supported:

- ◆ NTFS (optimal)
- ◆ FAT32
- ◆ HFS+/Mac OS Extended (non-journaled)
- ◆ Linux file systems

**IMPORTANT INFO:** External USB hard drives formatted in HFS+ (journaled) are not compatible with the LaCinema PlayHD.

## 6.3. Safe USB Disk Removal

Click the  (Eject) button on the remote control. Confirm that the USB disk can be safely removed from the LaCinema PlayHD before disconnecting it ([Fig. 52](#)).

**IMPORTANT INFO:** If the disk is not properly disconnected, the data could be damaged. Make sure that you always safely eject disks before disconnecting them.




Fig. 51



Fig. 52

## 7. Settings Menu

The [Setup Space](#) will help you configure and customize your LaCinema PlayHD. Access the [Setup Space](#) by navigating to the gear icon on the PlayHD menu ([Fig. 53](#)).

Scroll through the Setup menu using the [Up](#) ▲ and [Down](#) ▼ buttons ([Fig. 53](#)). You can select [General](#), [Audio/Video](#), or [System](#).

To display the options for a setup category, press the **OK** button. All changes are automatically saved.

To select another option, press the [Return](#) ← button to return to a previous menu.

To exit the setup menu, press the [Setup](#) ⚙ button.




Fig. 53

### 7.1. Settings: General

Fig. 54

- ◆ Change the menu language, subtitle format, or screen saver settings
- ◆ Update the Media Library information



Fig. 54

#### 7.1.1. Menu Language

Select [Menu Language](#) to change the language of the LaCinema PlayHD menu language ([Fig. 55](#)).



Fig. 55

7.1.2. Subtitle Format

You may change the default subtitle format (Fig. 56). See 1.5. Supported Subtitles for more information on supported subtitle formats.

7.1.3. Screen Saver

The LaCinema PlayHD has a screen saver for inactive periods. Select the time of inactivity that will trigger the screen saver (Fig. 57).

7.1.4. Media Library

Your LaCinema PlayHD will find all media files copied to its internal hard drive or stored on an external USB storage devices attached to the front USB 2.0 port. However, there may be times when the media is not classified by genre or artist.

The LaCinema PlayHD can scan its internal hard disk and external USB disk drives for media files (Fig. 58).

For example, you recently attached the LaCinema PlayHD to your computer to copy additional music files. When you reconnect the device to the television, you see the files in the Music Space but they are not listed under the artist’s name.

To have the LaCinema PlayHD search through its files, select **Scan Now**. The files should be classified once the scan is finished. The default setting is **Auto scan off**.



Fig. 56




Fig. 57




Fig. 58

## 7.2. Settings: Audio/Video

Fig. 59

- ◆ Adjust settings for video resolution and aspect ratio
- ◆ Change the HDMI and coaxial audio output settings
- ◆ View movies at their native rate

### 7.2.1. Resolution

Choose a display resolution to match your television (Fig. 60 - the default is [HDMI Auto](#)).

### 7.2.2. Aspect Ratio

Adjust the aspect ratio of the LaCinema PlayHD to match your television (Fig. 61):

- ◆ 16:9
- ◆ Pan Scan 4:3
- ◆ Letterbox 4:3



Fig. 59



Fig. 60



Fig. 61

### 7.2.3. HDMI Audio

Select the audio signal output via HDMI (Fig. 62):

- ◆ **Decode** - Best suited when connecting the HDMI cable to your television. Surround formats will be mixed down for stereo output.
- ◆ **Pass through** - Best suited when connecting the HDMI cable to a digital receiver/pre-amplifier for surround sound audio. Surround sound formats feature multichannel audio output to more than two speakers. Examples may be 5.1 surround sound (five speakers and one sub-woofer) or 7.1 surround sound (seven speakers and one sub-woofer).

---

**IMPORTANT INFO:** You may want to connect the coaxial cable (S/PDIF) to a digital receiver/pre-amplifier when using the HDMI for the TV. In such a case, LaCie highly recommends selecting the **Decode** option for HDMI Audio.

---




Fig. 62

### 7.2.4. S/PDIF Audio

Select the audio signal output via the coaxial cable (Fig. 63):

- ◆ **Decode** - Surround formats will be mixed down for stereo output.
- ◆ **Pass through** - Best suited when connecting the coaxial cable to a digital receiver/pre-amplifier for surround sound audio. Surround sound formats feature multichannel audio output to more than two speakers. Examples may be 5.1 surround sound (five speakers and one sub-woofer) or 7.1 surround sound (seven speakers and one sub-woofer).




Fig. 63

### 7.2.5. 1080P 24Hz

This setting allows you to view movies specifically shot and recorded as film. The 24 Hz indicates that the field rate is 24 fields per second. Since the field rate is not standard, the default for this setting is **Off**.

LaCie recommends using this option only when you know that one or more media files are compatible with 1080P 24 Hz. When you have compatible files, you can reproduce the original frame rate by turning the **1080P 24 Hz** option **On**.

---

## 7.3. Settings: System

Fig. 64

- ◆ Review and update the LaCinema PlayHD firmware
- ◆ Reformat the internal hard disk
- ◆ Reset the LaCinema PlayHD to factory settings

### 7.3.1. Version

View the firmware version of your LaCinema PlayHD (Fig. 65).

### 7.3.2. Firmware Update

LaCie highly recommends that you search for firmware updates to your LaCinema PlayHD:

1. Find the version of the current firmware (see 7.3.1. Version).
2. Visit [www.lacie.com](http://www.lacie.com)
3. Go to the PlayHD product page. Since there are a range of LaCinema products, please make certain that you are on the PlayHD site.
4. Select the [Support](#) tab.
5. Compare the version of firmware available on the website with the version on your LaCinema PlayHD. If the version on the LaCinema PlayHD website is more recent, please download it to your computer.
6. Unzip the file before copying the firmware update to the root of a USB flash drive or USB key. The PlayHD will not find the update if it is placed within a folder on the USB flash drive or key.
7. Safely eject the USB flash drive or USB key safely from your computer and insert it into the front USB 2.0 port of the LaCinema PlayHD.
8. Using the LaCinema PlayHD remote, navigate to **Settings > System > Firmware Update**.

**TECHNICAL NOTE:** If the LaCinema PlayHD does not find the firmware update on the USB flash drive or key, you will see the message in Fig. 66. Eject the USB flash drive or key and try again. If the problem persists, please plug the USB flash drive or key into your computer to confirm that the firmware update is present. As well, return to the PlayHD product site at [www.lacie.com](http://www.lacie.com) to make certain that the update is correct.




Fig. 64




Fig. 65




Fig. 66

continued on the next page>>

9. The LaCinema PlayHD should find the firmware update on your USB flash drive or key (Fig. 67). Click **OK** to proceed with the update.
10. A window prompt will ask you to keep the LaCinema PlayHD powered on during the update. You may damage the PlayHD if you turn the power off or unplug the USB flash drive or key during the firmware update.
11. A final window prompt will let you know that the update was successful and that the LaCinema PlayHD will restart.

---

### 7.3.3. HDD Format (Formatting the internal hard disk)

You can reformat the LaCinema PlayHD in NTFS. See 8.3. [Reformatting: The LaCinema PlayHD TV Menu](#) for further details.

---

**CAUTION:** Formatting will erase all media files from the LaCinema PlayHD. Back up all media that you want to protect or continue to use before you format the disk drive. Please note that your PlayHD settings will be preserved (i.e. language).

---

### 7.3.4. Factory Default

For troubleshooting purposes, you may revert the LaCinema PlayHD to its initial settings (Fig. 68). Only your settings will be erased as the media remains intact.

At the window prompt, select **Yes** to reset the PlayHD to its factory settings. The device will automatically restart. Complete the installation wizard to access your media files (4.3. [STEP 4: Complete the Installation Wizard](#)).

---



Fig. 67



Fig. 68

## 8. Reformatting the LaCinema PlayHD Hard Disk

Your LaCinema PlayHD is preformatted and optimized for NTFS. It is ready to receive media content from a Windows computer straight out of the box. You may reformat the LaCinema PlayHD on a computer ([8.1. Reformatting: Windows](#) and [8.2. Reformatting: Mac Users](#)) or on the device itself.

---

**IMPORTANT INFO FOR MAC USERS:** While the PlayHD will work with the Mac OS HFS+ (non-journaled) format, it offers improved performance when formatted in Windows NTFS. If your Macintosh computer includes third-party applications or drivers that permit writing to NTFS, LaCie highly recommends maintaining NTFS as the drive format for the PlayHD.

---

---

**IMPORTANT INFO:** Please note that the Mac disk format HFS+ (journaled) is not supported on the LaCinema PlayHD. LaCie cannot guarantee performance if you format the LaCinema PlayHD's internal hard drive in HFS+ (journaled).

---

	NTFS	HFS+ (non-journaled)	MS-DOS (FAT32)
Windows	<ul style="list-style-type: none"><li>◆ Optimized performance when using the LaCinema PlayHD.</li><li>◆ Supports file sizes greater than 4GB</li><li>◆ More suited for high definition media content.</li></ul>	<ul style="list-style-type: none"><li>◆ HFS+ is not recommended for Windows.</li></ul>	<ul style="list-style-type: none"><li>◆ Compatible with Windows and Mac</li><li>◆ A maximum single file size restriction of 4GB.</li><li>◆ Not suited for larger high definition media content.</li></ul>
Mac	<ul style="list-style-type: none"><li>◆ The Mac OS can read and copy files from NTFS disks.</li><li>◆ The Mac OS requires third-party software or drivers to write to NTFS disks.</li></ul>	<ul style="list-style-type: none"><li>◆ In most instances, HFS+ (non-journaled) offers very good performance for Macintosh systems.</li><li>◆ Supports file sizes greater than 4GB.</li><li>◆ More suited for high definition media content.</li><li>◆ If your Macintosh computer includes third-party applications or drivers that permit writing to NTFS, LaCie highly recommends maintaining NTFS as the drive format for the PlayHD.</li></ul>	<ul style="list-style-type: none"><li>◆ Compatible with Windows and Mac</li><li>◆ A maximum single file size restriction of 4GB.</li><li>◆ Not suited for larger high definition media content.</li></ul>

Once you have chosen a file format, see sections [8.1. Reformatting: Windows](#), [8.2. Reformatting: Mac Users](#), or [8.3. Reformatting: The LaCinema PlayHD TV Menu](#) for instructions on formatting your LaCinema PlayHD.

---

## 8.1. Reformatting: Windows

### 8.1.1. Formatting for Windows XP

The steps listed below will help you format and partition your LaCinema PlayHD disk drive using Windows XP. Please see [8.1.2. Formatting for Windows Vista/7](#) or [8.2. Reformatting: Mac Users](#) for instructions on formatting with alternative operating systems. For more information on the optimal file format, go to [8. Reformatting the LaCinema PlayHD Hard Disk](#).

**CAUTION:** Following these steps will erase all media files from the LaCinema PlayHD. Back up all data that you want to protect or continue to use before you format the disk drive. Please note that your PlayHD settings will be preserved (i.e. language).

1. Connect the drive to the computer via the interface port.
2. Right-click **My Computer** and select **Manage**.
3. From the "Computer Management" window, select **Disk Management** (located below the **Storage** group). See [Fig. 69](#).
4. If the "Initialize and Convert Disk Wizard" window appears, click **Cancel**.
5. Windows will list the Hard Disks that are installed on the system. Locate the LaCie hard disk ([Fig. 69](#)). Right-click the icon and select **Initialize**.
6. In the box to the right that says **Unallocated**, right-click and select **New Partition...**
7. On the first page of the "New Partition Wizard," click **Next** ([Fig. 70](#)).
8. Select the **Primary** or **Extended** option ([Fig. 71](#)) and click **Next**.

continued on next page>>




Fig. 69




Fig. 70




Fig. 71

9. Specify the partition size. By default, the partition occupies the entire volume (Fig. 72). Click **Next**.
10. Assign a drive letter or mount path (Fig. 73). Click **Next**.
11. Select the file format for the disk (FAT32 will only appear as an option if the partition is 32GB or less). Once FAT32 or NTFS has been selected (Fig. 74), you have the option to **Perform a quick format**, which allows for a much faster format. While Disk Management does not check the drive for errors as extensively with a quick format, the option does save time. Click **Next**.

continued on next page>>




Fig. 72




Fig. 73




Fig. 74

12. A window appears listing your choices. If all seems well, click **Finish** to begin the format process (Fig. 75). To make a change, select **Back**.
13. Windows Disk Management will format and partition the disk according to your settings (Fig. 76), and your drive will appear in **My Computer**, ready to use.

---

**IMPORTANT INFO:** MS-DOS (FAT32) is compatible with Windows and Mac operating systems. However, it is not the optimal format for high definition multimedia content due to file size restriction.

---




Fig. 75




Fig. 76

### 8.1.2. Formatting for Windows Vista/7

#### Master Boot Record or GUID Partition Table?

Master Boot Record (MBR) partitioning has been the hard drive standard for many years. It supports a maximum of four primary partitions with a size limit of 2TB per partition. Due to partition limitations in the face of ever-expanding hard disk drive sizes, Global Unique Identifier Partition Tables (GPT) has been established. It allows for more partitions with greater capacities. Further, GPT has many additional advantages that may offer enhancements in performance.

However, GPT is not compatible with Windows XP 32-bit. While Windows XP 64-bit supports GPT, it is best to use MBR if you intend to share your LaCie device with computers running Windows XP 32-bit.

Switching from MBR to GPT or, conversely, from GPT to MBR, is not difficult. Please copy all important data to a separate disk before making the change since adjusting the partition table format is destructive:

Right-click on **Computer** and choose **Manage**. From the **Manage** window select **Disk Management** and find your LaCie disk drive. Right-click on the disk number to choose GPT (Fig. 78) or MBR (Fig. 79).

The steps listed below will help you format and partition your disk drive using Windows Vista or Windows 7. Please see [8.1.1. Formatting for Windows XP](#) or [8.2. Reformatting: Mac Users](#) for instructions on formatting using alternative operating systems. For more information on the optimal file format, go to [8. Reformatting the LaCinema PlayHD Hard Disk](#).

**CAUTION:** Following these steps will erase all media files from the LaCinema PlayHD. Back up all media that you want to protect or continue to use before you format the disk drive. Please note that your PlayHD settings will be preserved (i.e. language).

1. Right-click on **Computer** and choose **Manage**. From the **Manage** window select **Disk Management**.
2. From the list of drives in the middle of the **Disk Management** window, right-click on your LaCie hard drive. Select **New Simple Volume...** (Fig. 77)

continued on next page>>




Fig. 77




Fig. 78




Fig. 79

3. The **New Simple Volume Wizard** will appear. To continue choose **Next**. (Fig. 80)
4. This wizard allows you to create volumes, also known as partitions. You can choose to create a single partition or many. Type the size of the partition you want to create in megabytes (MB). For example, a 100GB (gigabyte) partition is 100000MB. (Fig. 81) Once you have chosen a partition size, select **Next**.

continued on next page>>



Fig. 80




Fig. 81

5. Assign a drive letter or accept the default. (Fig. 82) Select **Next**.
6. Choose the file system format for the partition. If the partition size is 32GB or less, the choices will include **NTFS** and **FAT32**. Once the format is selected, you may check **Perform a quick format**, which allows for a much faster format. While Disk Management does not check the drive for errors as extensively with a quick format, the option does save time (Fig. 83). Select **Next**.

continued on next page>>




Fig. 82




Fig. 83

---

**TECHNICAL NOTE:** Windows Vista SP1/SP2 and Windows 7 offer the exFAT file system, which is not limited to partitions less than 32GB (Fig. 83). Used primarily with USB flash drives, the exFAT file system overcomes many of the limitations of FAT32. In addition to Windows Vista SP1 and Windows 7, the exFAT file system can work on Windows XP SP2 with a special driver. Mac OS support is questionable, which limits sharing your LaCie drive between Windows and Apple operating systems. LaCie does not support using the LaCinema PlayHD with the exFAT file system.

---

7. The last window is a summary of the format options you have just selected. If all looks to be correct, click **Finish** for the format to begin (Fig. 85).
8. See [3. Setting Up: Transferring Files](#) to begin copying media files to your LaCinema PlayHD.




Fig. 84




Fig. 85

## 8.2. Reformatting: Mac Users

**IMPORTANT INFO FOR MAC USERS:** While the PlayHD will work with the Mac OS HFS+ (non-journaled) disk format, it offers improved performance when formatted in NTFS. If your Macintosh computer includes third-party applications or drivers that permit writing to NTFS, LaCie highly recommends maintaining NTFS as the drive format for the PlayHD.

The steps listed below will help you format and partition your disk drive using Mac OS X. Please see [8.1.1. Formatting for Windows XP](#) or [8.1.2. Formatting for Windows Vista/7](#) for instructions on formatting using alternative operating systems. For more information on the optimal file format, go to [8. Reformatting the LaCinema PlayHD Hard Disk](#).

**CAUTION:** Following these steps will erase all media files from the LaCinema PlayHD. Back up all media that you want to protect or continue to use before you format the disk drive. Please note that your PlayHD settings will be preserved (i.e. language).

1. Connect the drive to the computer via the interface port.
2. Select **Utilities** from the **Go** menu in the Finder menu bar.
3. In the Utilities folder, double-click **Disk Utility**.
4. The Disk Utility window will open ([Fig. 86](#)). Select your LaCie hard disk from the list of available hard disks on the left side of the window.
5. Select the **Partition** tab ([Fig. 87](#)).

continued on next page>>




Fig. 86




Fig. 87

6. From the **Volume Scheme:** menu, choose the number of partitions for the disk drive using the pull-down menu (Fig. 88 (6a)) - Mac OS X gives you the option of dividing the drive into a maximum 16 partitions). You can adjust the size of each partition using the slide bar between the partitions in the **Volume Scheme:** area (Fig. 88 (6b)) or write the size manually in the Size box. (Fig. 88 (6c)).
7. Click on a volume (partition) in Volume Scheme so that a name can be entered in the Volume Information section (Fig. 88 (7a)). From the volume Format pull-down list (Fig. 88 (7b)), select one of the following Mac formats: **Mac OS Extended (Journaled)**, **Mac OS Extended**, **Mac OS Extended (Case-sensitive, Journaled)**, **Mac OS Extended (Case-sensitive)** or **Free Space**. To format a partition FAT32, you must select **Options...** (Fig. 88 (7c)) below the list of partitions and choose the radio button for **Master Boot Record** (Fig. 89). **MS-DOS (FAT)** will appear on the pull-down list of Formats (Fig. 88 (7b)).
8. Once you have finalized the volume options, click **Apply** (Fig. 88 (8a)). Click **Partition** (Fig. 90) when the alert message appears.
9. Disk Utility will format and partition the disk according to your settings. Once finished, the partition(s) will appear on your desktop, indicating the disk drive is ready for use.
10. See 3. [Setting Up: Transferring Files](#) to begin copying media files to your LaCinema PlayHD.




Fig. 88




Fig. 89



Fig. 90

### 8.3. Reformatting: The LaCinema PlayHD TV Menu

The LaCinema PlayHD internal hard disk may be formatted using the menu. Choosing this method will reformat the disk in NTFS.

**CAUTION:** Following these steps will erase all media files from the LaCinema PlayHD. Back up all data that you want to protect or continue to use before you format the disk drive. Please note that your PlayHD settings will be preserved (i.e. language).

1. Go to **Home > Settings > Setup > HDD > Format**. A series of prompts will guide you through the disk format. Make certain to read each window carefully before responding.
2. The **Format** window asks if you wish to format your LaCinema PlayHD (Fig. 91). Click **CANCEL** to leave the format operation or **Yes** to continue.
3. The **Warning** window notifies you that the format will erase all data on the LaCinema PlayHD (Fig. 92). Click **CANCEL** to leave the format operation or **OK** to continue.
4. The **Confirmation** window notes one last time that you are about to delete all your media files (Fig. 93). Your settings will be kept (i.e. language). Click **CANCEL** to leave the format operation or **Format** to continue.

[continued on next page>>](#)




Fig. 91




Fig. 92



Fig. 93

5. Please do not unplug the power to your LaCinema PlayHD during the format ([Fig. 94](#)).
  6. You will receive a window prompt announcing that the format is finished ([Fig. 95](#)). Click Restart to reinitialize the LaCinema PlayHD.
  7. See [3. Setting Up: Transferring Files](#) to begin copying media files to your LaCinema PlayHD.
- 



Fig. 94

---




Fig. 95

---

## 9. Technical Information

### 9.1. HD File Format Compatibility

The LaCinema PlayHD is fully compatible with the high definition formats below:

- ◆ AVC HD
  - ◆ H.264 (MPEG-4 P10)
  - ◆ MPEG-2 HD
  - ◆ MPEG-4.2
  - ◆ WMV9
  - ◆ VC-1
  - ◆ Xvid
- 

### 9.2. Optimizing Data Transfers

Data transfers for the LaCinema PlayHD are the flow of data from computer RAM to storage, or between storage devices. With external drives, such as the LaCinema PlayHD, the data is transferred from the computer to the drive via the USB interface.

#### USB

For Hi-Speed USB 2.0 performance, your computer must be equipped with a Hi-Speed USB 2.0 host bus adapter card. The USB 2.0 port can be integrated into your computer's motherboard or sold separately as a peripheral device. Operating systems compatible with the PlayHD include drivers that support USB 2.0 disk drives.

For information about Hi-Speed USB 2.0 peripheral cards, visit our website: [www.lacie.com](http://www.lacie.com).

---

## 10. Troubleshooting

If your LaCinema PlayHD does not work properly, please refer to the Troubleshooting table to find a solution. You may also visit the PlayHD product page on the LaCie website for recent information concerning the device: [www.lacie.com](http://www.lacie.com).

If you need further assistance, please contact your LaCie reseller or LaCie Customer Support (see section [11. Contacting Customer Support](#) for details).

### Manual Updates

LaCie strives to offer comprehensive, up-to-date User Manuals. It is our goal to provide you with a friendly, easy-to-use format that will help you quickly install and utilize your new device.

If your User Manual does not reflect the configuration of the product you purchased, please check our website for a current version.

[www.lacie.com](http://www.lacie.com)

---

## 10.1. Troubleshooting the Television/Stereo Connection

Problem	Question	Answer
The TV does not recognize the connected disk.	Have you properly set the video out parameters in the <a href="#">Settings</a> menu?	Click the Info button on the PlayHD remote control to change from HDMI (default) to Composite Video Out mode. When switching, make certain to connect the proper cables to view the image ( <a href="#">4.1.1. HDMI (High Definition) Connection</a> and <a href="#">4.1.2. Composite Video &amp; Stereo Audio Cable</a> ).
Checking the firmware version.	How do you know which firmware version your LaCinema PlayHD is using?	See <a href="#">7.3.1. Version</a> for details on how to check the LaCinema PlayHD firmware.
	How do you download and install new firmware?	For a detailed explanation, please see <a href="#">7.3.2. Firmware Update</a> .
There is no picture being displayed.	Are all of the cables connected correctly?	Ensure that all of the cables are connected correctly. See section <a href="#">4. Setting Up: TV Connection</a> .
The picture is black and white or there is no image on the television.	Is the LaCinema PlayHD properly connected?	Make certain that the video setting on your television matches the cable connection from the LaCinema PlayHD.
	Are the video settings correct?	Make certain that all the cable are in place and not loosely connected to the ports on the television or the LaCinema PlayHD.  If the video is present but discolored, press the <a href="#">Info</a> button on the remote control until the correct image is displayed. Go to the <a href="#">Settings</a> menu and select <a href="#">Video</a> . From there, you can select the correct settings. For more information, please see section <a href="#">7.2. Settings: Audio/Video</a> .
Optimizing video connections.	What video connection will offer the best picture quality?	Under most circumstances, the optimal video connection is HDMI (cable included).
There is no sound when connecting the LaCinema PlayHD to a digital stereo.	Have the Audio Settings been adjusted?	No matter if you are using the HDMI or analog outputs from the PlayHD, the picture and sound should play on your television if the cables have been properly connected. Please check your television video and audio playback settings to make certain that they match the cable connections.  If you have connected the coaxial cable or HDMI cable to your digital receiver/pre-amplifier, please see the device user manual to determine how to hear audio. As well, you must adjust the settings on the LaCinema PlayHD. See for <a href="#">7.2.3. HDMI Audio</a> HDMI and <a href="#">7.2.4. S/PDIF Audio</a> for coaxial.
Slideshows are sluggish.	Does it take several seconds to load a picture?	Depending on file size, photos may take several seconds to load properly. Reducing photo resolution may allow files to load faster during a slideshow.

## 10.2. USB Connection (Mac Users)

Problem	Question	Answer
The drive is not recognized by the computer.	Does an icon for the drive appear on the desktop?	Unless you have set the Finder preference not to show External disks on the desktop, an icon for the LaCie drive will be visible. If the drive does not appear, follow the rest of the Troubleshooting tips to isolate the problem.
	Does your computer's configuration meet the minimum system requirements for use with this drive?	See <a href="#">1.1. Computer Minimum System Requirements</a> for more information.
	Is the drive's power supply connected?	Make sure that the power supply is properly connected (see <a href="#">3.1. STEP 1: Connect the Power Supply</a> ) and that the outlet is working.
	Are both ends of the USB cable securely attached?	<ul style="list-style-type: none"> <li>◆ Only use a USB cable provided by LaCie.</li> <li>◆ Check both ends of the USB cable to make sure they are fully seated in their respective ports.</li> <li>◆ Try disconnecting the cables, waiting 10 seconds, and then reconnecting them.</li> <li>◆ If the drive is still not recognized, restart your computer and try again.</li> </ul>
	Is there a conflict with other device drivers or extensions?	Contact LaCie Technical Support for help.
	Does your computer's operating system support the hard disk file system?	See section <a href="#">8. Reformatting the LaCinema PlayHD Hard Disk</a> for more information.
Error messages under Mac OS 10.x.	Is there an "Error -50" message while copying to a FAT 32 (MS-DOS) volume?	<p>When copying files or folders from Mac OS 10.x to a FAT 32 volume, file names with certain characters cannot be copied. These characters include, but are not limited to:</p> <p>? &lt; &gt; / \ :</p> <p>Check your files and folders to ensure that these characters are not being used.</p>
The drive is not running noticeably faster when connected via Hi-Speed USB 2.0.	Are you operating in Mac OS 9.x?	The LaCinema PlayHD is not compatible with Mac OS 9.x.
	Is the drive connected to a standard USB port on your computer?	Performance will be affected if your drive is connected to a standard USB port. A Hi-Speed USB 2.0 device can only operate at Hi-Speed USB 2.0 performance levels when it is connected directly to a Hi-Speed USB 2.0 port. Otherwise, the Hi-Speed USB 2.0 device will operate at the slower USB transfer rates. For more information, please see sections <a href="#">9.2. Optimizing Data Transfers</a> and <a href="#">1.7. Cables and Connectors</a> .
	Is the drive connected to a Hi-Speed USB 2.0 port on your computer?	Check to see that the Hi-Speed USB 2.0 drivers for both your host bus adapter and device have been installed correctly. If in doubt, un-install the drivers and re-install them. Also, make sure that you are connected directly to a Hi-Speed USB 2.0 port on your computer. Performance for the LaCinema PlayHD is not guaranteed when connected to a hub.

## 10.3. USB Connection (Windows Users)

Problem	Question	Answer
The drive is not recognized by the computer.	Has the drive been formatted?	Make sure that the drive has been formatted properly. Please see <a href="#">8. Reformatting the LaCinema PlayHD Hard Disk</a> .
	Does your operating system support the disk file system format?	Check your computer's documentation and see <a href="#">8. Reformatting the LaCinema PlayHD Hard Disk</a> .
	Is there an icon for the drive in <a href="#">My Computer/Computer</a> ?	Go to <a href="#">My Computer/Computer</a> and look for an icon and drive letter assigned to the LaCie drive. If the drive does not appear, follow the rest of the Troubleshooting tips to isolate the problem.
	Does your computer meet the minimum system requirements for use with this drive?	See section <a href="#">1.1. Computer Minimum System Requirements</a> for more information.
	Is the drive's power supply connected?	Make sure that the power supply is properly connected (see section <a href="#">3.1. STEP 1: Connect the Power Supply</a> ) and that the outlet is working.
	Are both ends of the USB cables firmly attached?	Check both ends of the USB cable to make sure they are fully seated in their respective ports. Try disconnecting the cables, waiting 10 seconds, and then reconnecting them. If the drive is still not recognized, restart your computer and try again.
	Is there a conflict with other device drivers or extensions?	Check the website support page for updated information on potential conflicts ( <a href="http://www.lacie.com">www.lacie.com</a> ). Contact LaCie Technical Support for help.
The drive is not running noticeably faster when connected via Hi-Speed USB 2.0.	Is the drive connected to a standard USB port on your computer?	Performance will be affected if your drive is connected to a standard USB port. A Hi-Speed USB 2.0 device can only operate at Hi-Speed USB 2.0 performance levels when it is connected directly to a Hi-Speed USB 2.0 port. Otherwise, the Hi-Speed USB 2.0 device will operate at the slower USB transfer rates. For more information, please see sections <a href="#">9.2. Optimizing Data Transfers</a> and <a href="#">1.7. Cables and Connectors</a> .
	Is the drive connected to a Hi-Speed USB 2.0 port on your computer?	Check to see that the Hi-Speed USB 2.0 drivers for both your host bus adapter and device have been installed correctly. If in doubt, un-install the drivers and re-install them. Also, make sure that you are connected directly to a Hi-Speed USB 2.0 port on your computer. Performance for the LaCinema PlayHD is not guaranteed when connected to a hub.

# 11. Contacting Customer Support

## Before You Contact Technical Support

- 1. Read the User Manual and review section 10. *Troubleshooting*.
- 2. Try to isolate the problem. If possible, make the drive the only external device on your computer or TV.
- 3. Make sure that all of the cables are correctly and firmly attached.

If you have asked yourself all of the pertinent questions from troubleshooting and the problem persists, contact us at [www.lacie.com](http://www.lacie.com). Please make certain that you are in front of your computer and that you have the following information on hand:

Information	Location
LaCie hard drive serial number	Located on a sticker at the back of drive or on the original packaging
LaCinema PlayHD firmware version	See 7.3.1. <i>Version</i>
Macintosh/PC model	<b>Mac users:</b> Click on the Apple icon in the menu bar and select <b>About This Mac</b> .
Operating system version	
Processor speed	
Computer memory	<b>Windows users:</b> Right click <b>My Computer</b> and select <b>Properties &gt; General</b> .
The brands and models of other internal and external peripherals installed on your computer	<b>Mac users:</b> Click on the Apple icon in the finder bar and select <b>About This Mac</b> . Select <b>More Info...</b> The Apple System Profiler will launch and will list your internal and external peripherals.  <b>Windows users:</b> Right click <b>My Computer</b> and select <b>Properties &gt; Hardware</b> .

## 11.1. LaCie Technical Support Contacts

LaCie Asia <a href="http://www.lacie.com/cn/contact/">http://www.lacie.com/cn/contact/</a>	LaCie Australia <a href="http://www.lacie.com/au/contact/">http://www.lacie.com/au/contact/</a>
LaCie Belgium <a href="http://www.lacie.com/be/contact/">http://www.lacie.com/be/contact/</a> (Dutch) <a href="http://www.lacie.com/befr/contact/">http://www.lacie.com/befr/contact/</a> (French)	LaCie Brazil <a href="http://www.lacie.com/us/contact/">http://www.lacie.com/us/contact/</a>
LaCie Canada <a href="http://www.lacie.com/ca/contact/">http://www.lacie.com/ca/contact/</a> (English) <a href="http://www.lacie.com/cafr/contact/">http://www.lacie.com/cafr/contact/</a> (French)	LaCie Denmark <a href="http://www.lacie.com/dk/contact/">http://www.lacie.com/dk/contact/</a>
LaCie Finland <a href="http://www.lacie.com/fi/contact/">http://www.lacie.com/fi/contact/</a>	LaCie France <a href="http://www.lacie.com/fr/contact/">http://www.lacie.com/fr/contact/</a>
LaCie Germany <a href="http://www.lacie.com/de/contact/">http://www.lacie.com/de/contact/</a>	LaCie Ireland <a href="http://www.lacie.com/ie/contact/">http://www.lacie.com/ie/contact/</a>
LaCie Italy <a href="http://www.lacie.com/it/contact/">http://www.lacie.com/it/contact/</a>	Japan – Elecom CO., LTD. <a href="http://www.lacie.jp">http://www.lacie.jp</a>
LaCie Korea <a href="http://www.lacie.com/kr/contact/">http://www.lacie.com/kr/contact/</a>	LaCie Latin America <a href="http://www.lacie.com/la/contact/">http://www.lacie.com/la/contact/</a>
LaCie Netherlands <a href="http://www.lacie.com/nl/contact/">http://www.lacie.com/nl/contact/</a>	LaCie Norway <a href="http://www.lacie.com/no/contact/">http://www.lacie.com/no/contact/</a>
LaCie Portugal <a href="http://www.lacie.com/pt/contact/">http://www.lacie.com/pt/contact/</a>	LaCie Singapore <a href="http://www.lacie.com/asia/contact/">http://www.lacie.com/asia/contact/</a>
LaCie Southeast Asia <a href="http://www.lacie.com/sea/contact/">http://www.lacie.com/sea/contact/</a>	LaCie Spain <a href="http://www.lacie.com/es/contact/">http://www.lacie.com/es/contact/</a>
LaCie Sweden <a href="http://www.lacie.com/se/contact/">http://www.lacie.com/se/contact/</a>	LaCie Switzerland <a href="http://www.lacie.com/ch/contact/">http://www.lacie.com/ch/contact/</a> (German) <a href="http://www.lacie.com/chfr/contact/">http://www.lacie.com/chfr/contact/</a> (French) <a href="http://www.lacie.com/chit/contact/">http://www.lacie.com/chit/contact/</a> (Italian)
LaCie UK <a href="http://www.lacie.com/uk/contact/">http://www.lacie.com/uk/contact/</a>	LaCie USA <a href="http://www.lacie.com/us/contact/">http://www.lacie.com/us/contact/</a> (English) <a href="http://www.lacie.com/uses/contact/">http://www.lacie.com/uses/contact/</a> (Spanish)
LaCie Grand Export <a href="http://www.lacie.com/intl/contact/">http://www.lacie.com/intl/contact/</a>	

## 12. Warranty Information

LaCie warrants your drive against any defect in material and workmanship, under normal use, for the period designated on your warranty certificate. In the event this product is found to be defective within the warranty period, LaCie will, at its option, repair or replace the defective drive.

This warranty is void if:

- ◆ The drive was operated/stored in abnormal use or maintenance conditions;
- ◆ The drive is repaired, modified or altered, unless such repair, modification or alteration is expressly authorized in writing by LaCie;
- ◆ The drive was subjected to abuse, neglect, lightning strike, electrical fault, improper packaging or accident;
- ◆ The drive was installed improperly;
- ◆ The serial number of the drive is defaced or missing;
- ◆ The broken part is a replacement part such as a pickup tray, etc.
- ◆ The tamper seal on the drive casing is broken.

LaCie and its suppliers accept no liability for any loss of data during the use of this device, or for any of the problems caused as a result.

LaCie will not, under any circumstances, be liable for direct, special or consequential damages such as, but not limited to, damage or loss of property or equipment, loss of profits or revenues, cost of replacement goods, or expense or inconvenience caused by service interruptions.

Any loss, corruption or destruction of data while using a LaCie drive is the sole responsibility of the user, and under no circumstances will LaCie be held liable for the recovery or restoration of this data.

Under no circumstances will any person be entitled to any sum greater than the purchase price paid for the drive.

To obtain warranty service, call LaCie Technical Support. You will be asked to provide your LaCie product's serial number, and you may be asked to furnish proof of purchase to confirm that the drive is still under warranty.

All drives returned to LaCie must be securely packaged in their original box and shipped with postage prepaid.

---

**IMPORTANT INFO:** Register online for free technical support:  
[www.lacie.com/register](http://www.lacie.com/register)

---